

# BOOMERANG STRAP SYSTEM INSTRUCTIONS

The large, thin washer should be placed between the instrument and the hub (failure to use the washer can damage the surface of the instrument).

Insert the attachment screw into threaded the insert on the back of the instrument. Use a 4 mm hex wrench, flat screwdriver, or coin to tighten the screw. The hub should be held firmly but still be able to rotate.

Rotate the arms into position for use, and attach conventional guitar style strap to the ends of the arms.

Place strap over the shoulder like a guitar, and adjust the position of arms and rotation of the hub to the desired position for play. The instrument should remain in position.

For storage, move the long arm toward the neck, and rotate the short arm back over the body.

To adjust the arm friction, tighten or loosen the two hex screws in the hub. The screw closest to the long arm should generally be tightened more than the other screw, to provide more friction on the long arm.

The hex wrench can be stored in the hole in the ends of the tubes, but care must be taken to insure that the hex wrench is not positioned where it will scratch the instrument when the arms are moved.



Arms in Playing Position



In Use



Strap Attachment



Adjusting Pivot Friction



Adjusting Long Arm Friction



Folded for Storage

