

NS CELLO END PIN INSTRUCTIONS

Attach knee rest pieces to the threaded insert in the main leg of the stand, as pictured below. Adjust the ends of the knee rest as shown. Tighten the thumbscrew on the back of the knee support to secure it in place.

The Cello is now ready to be screwed onto the stand using the large mounting bolt. The cello can be set at any comfortable angle.

To adjust the height of the cello, loosen the thumbscrew at the bottom of the main leg, as shown. Extend or retract the end pin, and retighten the thumbscrew.

The knee rest parts are removable for compact storage. Pack the end pin stand carefully so cello and end pin stand are not damaged in transport.



End Pin Parts



Attach Knee Rest



Adjust Knee Rest



Adjust Height



In Use



Fully Assembled